

## Container Handler

Used Container Handler Long Beach - Also known as container ships or cargo ships, container handlers use large intermodal containers to transport their goods. This type of shipping is called containerization and it is a specific kind of freight transport that carries non-bulk types of seagoing cargo. The capacity of these specialty ships is equal to twenty-foot loads. The majority of typical loads consist of a mix of 40-foot containers and 20-foot containers. Container ships are responsible for transporting roughly ninety percent of non-bulk items across the globe. Container handlers are one of the biggest vessels sailing and are the main rival for oil tankers on the ocean. Dry cargo is categorized into two main types: break-bulk cargo and bulk cargo. Grain and coal are bulk cargo, typically transported in their raw format inside the ships hull, free from packages. Manufactured goods that are in packages comprise the majority of break-bulk cargo. Before the 1950s when containerization hadn't been invented yet, break-bulk materials were loaded, secured and unattached one piece at a time in a very time-consuming process. Grouping cargo into containers allows for 1000-3000 cubic feet of cargo to be simultaneously moved once every container has been secured with standardization techniques. Efficiency has tremendously increased break-bulk cargo shipping. It is estimated that shipping time has been reduced by eighty-four percent and costs have been reduced by approximately thirty-five percent. More than ninety percent of non-bulk items were recorded as being transported in containers in 2001. The initial container ships in the 1940s were designed from tankers that were converted post-WWII. Container ships do not rely on individual hatches, holds and dividers that are part of regular cargo ships. Essentially the container ship's hull is similar to a huge warehouse that uses vertical guide rails to divide it into cells. These cells have been designed to transport the cargo in containers. Most shipping containers are constructed from steel; however, additional materials including plywood, fiberglass and wood are used. As containers have been designed to completely transferred to and from coastal carriers, semi-trailers, trucks, trains and more, these containers are categorized due to their function and size. Even though the shipping industry has been transformed by containerization, it took some time to streamline the process. Railway companies, ports and shippers were initially concerned about the extensive costs associated with building the railway infrastructure and ports required to accommodate container ships, along with moving the containers via road and rail. Various trade unions were skeptical about huge job loss with dock and port workers based on the assumption that containers would eliminate numerous cargo handling manual jobs among ports. Approximately ten years of legal battles occurred prior to container ships began international service. A container liner service from the Dutch city of Rotterdam to the USA first started in 1966, soon to change world trade and shipping across the globe. Loading and unloading of cargo ships has been reduced to a few hours instead of the days it used to take traditional cargo vessels. Shipping times have been shortened in between ports extensively along with labor finances. It only takes 3 weeks to have materials delivered from Europe to India as opposed to the months it used to require. Overall, there is less damaged cargo thanks to less physical handling and reduced cargo shifting due to properly securing loads. Containers are sealed prior to shipping and opened only once they arrive at their destination, resulting in less theft and disruption. Container ships have reduced shipping time and lessened shipping expenses, resulting in enhanced international trade growth. Cargo that used to arrive in bales, crates, bags, cartons or barrels now arrives in containers sealed from the factory. Scanning machines work with computers to trace the product code on the contents. Technology has made this tracking system accurate and exact to enable a two week voyage to be timed for arrival within an accuracy rate of under fifteen minutes. This has helped with guaranteed delivery and manufacturing times. Raw materials show up in sealed containers from factories in under an hour prior to being used in the manufacturing industry; resulting in fewer inventory expenses and greater accuracy. The shipping companies supply the exporters with boxes for loading products. They are delivered into the docks by rail or road or a combination of both to be loaded onto container ships. Containerization has streamlined

the process of loading by reducing the number of workers and hours it takes to fit cargo into their holds. The shipping industry today relies on cranes either installed on the ship or on the pier to situate containers on board. Once the hull has been completely loaded, more containers can be secured onto the deck. The key design element for container ships has been efficiency. Break-bulk ships may carry containers. However, cargo holds that have been dedicated to container ships have been carefully built to speed up the loading and unloading process and designed to keep containers secure while traveling the ocean. There is a sophisticated hatch design to allow openings from the main deck to reach the cargo hold locations. These openings flow along the whole cargo hold area and are surrounded by the hatch coaming which is a raised steel structure. There are hatch covers located on top of the hatch coamings. Wooden boards and tarps initially covered the hatches and held the battens secure until the 50s. These days, hatch covers often consist of solid metal plates that are lifted on and off the ship with cranes. Additional hatch models use hydraulic rams and articulated mechanisms for closing and opening. Cell guides are another main component within container ship design. Attached to the cargo hold in the ship, cell guides are vertical pieces of metal that help organize the cargo. These guide the containers into certain locations and offer travel support on the high seas. Since the design of the container ship utilizes cell guides in such abundance, the UN Conference on Trade and Development relies on them to separate traditional break-bulk cargo ships and container ships. There are three dimensions used in cargo plans to determine the position of the container on board the ship. The first coordinate is the bay which begins at the front of the ship and increases aft. The tier is the second coordinate, with the initial tier starting at the bottom of the cargo holds with the second, tier situated on top of the first and continuing on. The row is the third coordinate. Rows found on the port side of the ship exhibit even numbers and those located on the starboard side are given odd numbers. Rows found along the centerline are given lower numbers and these numbers increase for slots situated further from the center. Container handlers can handle forty-five, or forty or twenty-foot containers. The biggest sizes only fit above the deck. The forty-foot containers comprise most of the load or roughly 90% of container shipping. Container shipping is responsible for moving approximately ninety percent of the freight across the globe, while roughly eighty percent of global freight moves with 40 foot containers.